

## PETROL / Passenger cars

## Standard Service from \$359

## All Services based on 4.5 litres GT1 Flex 23 and Standard \$24 Oil Filter

- · Engine flush.
- Drain and change engine oil and change filter.
- Check dash warning lights.
- · Check lights, horn and wipers.
- · Check tyre condition, treat with silicone and adjust tyre pressures.
- · Check steering and suspension.
- · Check air filter.
- · Check cabin filter (if easily accessible).
- Test battery.
- · Check brake fluid and test.
- Check coolant and test.
- · Check transmission oil level and condition.
- · Check power steering fluid level and condition.
- Top up window washer fluid.
- Lubricate door locks and hinges.
- · Check fuel filter (visual).
- Check spark plugs (if easily accessible).
- Remove wheels and check brakes, check brake lines and hoses.
- Check CV boots.
- · Check Exhaust system for security or leaks.
- · Visual check of cooling system hoses.
- Check external drive belts.
- Visual check of disc brakes
- · Car Air freshener.
- Fuel system cleaner
- Road test and report.



